

Dear Customer,

Thank you for buying our UNDO dry erase film. We hope you will enjoy turning any of your surfaces into a creativity area.

To make sure your introduction with UNDO will be quick and fun we are providing some instructions for you on how to apply it.

We hope you enjoy it.

Feel free to share your thoughts with us.



1 Clean & Dry your chosen surface



2 Open the UNDO box and remove the small protective pieces of tape from the roll.



3 Put the roll back in the box and close it



4 Remove the perforated strip of cardboard from the top of the box



5 Pull the film through the opening



6 Cut the desired size of film, using the unique slide cutter on top of the box.



7 Begin to peel away the release liner paper and attach to chosen surface



8 Carefully remove the remaining liner, while attaching the film to surface.



9 Using a rag and side-to-side motion to avoid air bubbles forming.



10 Choose your favorite dry erase marker and start to create.

B.N#: